



GN SURGE W/CRANK STYLE STEM SETUP INSTRUCTIONS

Installation:

1. Remove 3/8" bolt and handle assembly from top of trailer. (See pic #1)
2. Carefully support coupler stem while loosening set screws, allow coupler stem to slide out of trailer. (See pic # 2)
3. Remove bearing and 3/8" thick washer from original stem and install on new Shockerhitch stem. Be careful - some bearing assemblies are two piece and will easily separate allowing ball bearings to scatter. (See pic # 3)

Note: A generous amount of grease should be applied to and around threaded shaft on new stem.

4. Carefully slide new Shockerhitch stem up into trailer until fully engaged and new crank stem is exposed at top of trailer, tighten set screws to support new stem. Install one 3/8" thick washer on exposed crank stem. Ram brand couplers already have one, the Bulldog brand couplers will require the addition of a 3/8" thick washer which is supplied with the Shockerhitch. (See pic #4)
5. Reinstall the crank handle with the 3/8" bolt. You are now ready to hook up and adjust the coupler for a level trailer.



STEP #1



STEP #2



STEP #3



STEP #4