



SHOCKER CHROME TRAILER HITCH BALL

-INSTALLATION

- Before installation, please be sure that the ball you selected fits the trailer coupler you are hooking up to and that the shank fits into the mount attachment with little to no wiggle room.
- Insert ball into the mount attachment in the correct orientation, slide lock washer onto shank, and hand tighten the ball nut onto the shank.
- Using a torque wrench, torque the ball nut to 450 ft. lbs of torque.

NOTES: To ensure ball won't come loose, it is recommended to use Loctite 290 on the threads of the ball shank after assembly.

SAFETY NOTICE: Towing capacity is limited by the lowest rated component. Do not exceed the G.V.W.R of the ball, mount attachment, or hitch being used.

SH-530 - 2"

10,000 lbs. GTW / 1,000 lbs. TW



SH-540 - 2-5/16" BALL

20,000 lbs. GTW / 2,000 lbs. TW



THANK YOU FOR CHOOSING SHOCKER HITCH

Shocker Hitch: Safer Smoother Towing - 2804 3RD AVE SW, JAMESTOWN ND, 58401 - (701)-707-2666

•Email: service@shockerhitch.com •Website: www.shockerhitch.com •Installation Videos on [Shocker Hitch](#) YouTube Channel