



PROTECTIVE VINYL WRAP FOR SHOCKER AIR BUMPER HITCH

-INSTALLATION

- Clean surface with mild soap and water to remove any dirt, grease, or grime. Rinse surface well with clean water to ensure no soap residue is left over. Dry with a lint-free or micro fiver (for best results).
- Wipe down surface with isopropyl alcohol and wipe down where vinyl wrap will be applied. Let completely dry.
- Pull vinyl wrap from backing paper and carefully apply wrap starting from the top and working downward, it is recommended to do this on a table with hitch laying on side.
- Be sure that the pin holes, pivot pin, and air valve holes line up evenly. Once lined up and material has made contact, firmly press vinyl wrap onto surface to adhere.
- Work out any air bubbles by firmly sliding outward. For best results, use a heat gun and lightly heat surface to help set the adhesive and/or wait 24 hours.

THANK YOU FOR CHOOSING SHOCKER HITCH

Shocker Hitch: Safer Smoother Towing - 2804 3RD AVE SW, JAMESTOWN ND, 58401 - (701)-707-2666

-Email: service@shockerhitch.com -Website: www.shockerhitch.com -Installation Videos on [Shocker Hitch](#) YouTube Channel